


Parts of the Grand Piano (Pianoforte)



- 1· Cast Iron Plate (Frame)
- 2· Bass Registry Hole
- 3· Stress Bars
- 4· Hitch Pins
- 5· Front Flange
- 6· Web

- 7· Agraffes (String Guides)
- 8· Capo D'astro Bar
- 9· Pin Block Web Space
- 10· Treble End Bar
- 11· Soundboard
- 12· Bass (Short) Bridge
- 13· Ribs (Belly Bars)
- 14· Treble (Long) Bridge
- 15· Rim (Case)
- 16· Inner Rim
- 17· Tone Collector

- 18· Braces (Beams)
- 19· Front Board
- 20· Pin-Block
- 21· Keybed
- 22· Treble Side Panel
- 23· Legs (shown shortened)
- 24· Hammers
- 25· Action
- 26· Keys
- 27· Keyframe