


Parts of the Trumpet



- 1· First Piston Valve
- 2· Second Piston Valve
- 3· Third Piston Valve
- 4· Mouthpiece
- 5· Mouthpiece Receiver
- 6· Lead Pipe

- 7· Bell
- 8· Finger Button
- 9· Top (Upper) Valve Cap
- 10· Valve Casing
- 11· Bottom (Lower) Valve Cap
- 12· First Valve Tuning Slide

- 13· Second Valve Tuning Slide
- 14· Third Valve Tuning Slide
- 15· Main Tuning Slide
- 16· Brace
- 17· Water Key
- 18· Pinky (Little Finger) Hook