


Parts of the Violin

(and other instruments of the violin family)



- 1· Top Block
- 2· Corner Blocks
- 3· Rib
- 4· Lining Strips
- 5· Bottom Block
- 6· Back Plate
- 7· Scroll
- 8· Pegs

- 9· Finger Board
- 10· Strings
- 11· Bridge
- 12· Tailpiece
- 13· End Button
- 14· Peg Box
- 15· Neck
- 16· Saddle (Nose)

- 17· F (Sound) Hole
- 18· Bass Bar
- 19· Top Plate (Belly)
- 20· Sound Post

- a· Upper Bout
- b· Center © Bout
- c· Lower Bout